

IMPROVE is a collaborative association of state, tribal, and federal agencies, and international partners. US Environmental Protection Agency is the primary funding source, with contracting and research support from the National Park Service. The Air Quality Research Center (AQRC) at the University of California, Davis provides field maintenance and operator support, sample handling, elemental analysis, and data processing; Research Triangle Institute (RTI) performs ions analysis; and Desert Research Institute (DRI) performs carbon analysis. IMPROVE data and


documentation are available from the website http://vista. cira.colostate.edu/improve/ maintained by the Cooperative Institute for Research in the Atmosphere (CIRA).


For questions or problems with optical or scene monitoring equipment, contact Mark Tigges, Air Resource Specialists, Fort Collins, CO at 970-224-9300. For questions or problems with air sampler controllers, filters or flow checks, contact Air Quality Research Center, UC Davis at 530-752-1123, or visit https://aqrc.ucdavis.edu/resources-for-operators.












- a. stack compression sleeve
- **b.** inlet stack
- c. braided hose
- d. inlet tee
- e. tee plug
- f. black cap
- . flow control valve
- h. pump hose connector
- . module cable connector
- i. motor control buttons
- k. electronics box (E-Box)
- . cyclone
- m. funnel
- n. cartridge with 4 filter cassettes
- o. solenoid manifold
- p. solenoid valve (4)
- q. motor assembly to raise solenoid manifold
- : handwheel to raise solenoid manifold





Disengaging Manifold Motor to Manually Raise/Lower the Manifold



Locate the motor assembly in the module.



Spin the hand wheel to the right to lower the manifold.



Separate the motor assembly from the coupling sliding the assembly down. Then pivot it towards to the hand wheel.



The spinning direction to raise and lower the manifold is opposite for the D module.



A gentle wiggle may be required to slide the assembly up or down.



If the motor starts to work again it can be reengaged with the hand wheel. Pivot the motor assembly back to its original location.



For the A, B, and C modules spin the hand wheel to the left to raise the manifold.



Rotate the hand wheel until the coupling snaps into alignment.

Electronics-Box Replacement (For A,B, and C modules. For the D module skip steps 3 and 9)



Disconnect the Orifice (ORI) and Cyclone (CYC) hoses by depressing the metal clasp and pulling on the hose.



Disconnect the grey cable located on top of the box by turning the metal collar counter-clockwise.



Disconnect the grey module cable at the bottom of the module, by turning the connector body counter-clockwise.



Loosen the brass knobs located on the black electronics box.



Remove old electronics box and insert the new box.



Tighten the brass knobs.



Re-connect grey cable on the top of the box.



(line up the key and keyway when connecting the electronic connectors)





IMPROVE operator training videos: https://aqrc.ucdavis.edu/resources-for-operators


UC Davis General Lab: 530-752-1123





Change Date/Time on Old Controller

(If the current time on your site is off by more than 5 minutes please call the Air Quality Group.)



Press **'Enter'** on the controller keypad to view the *Main Menu*.



If necessary change the *GMT time zone offset* using **'F1'** and **'F2'** to increase and decrease hours.

Press 'F3' to select plus or minus.

Press 'Enter' to continue.



Press 'F2' for Change Date & Time



Use **'F1'** and **'F2'** to set the current month. Then press **'F4'** to move onto the placeholder value for day, year, and time.

Press 'F3' to select previous placeholder values and 'Enter' to save.



Look up your time zone on the reference map and note the corresponding GMT offset in **Bold**.




Press 'Enter' once more to return to Auto Mode

Change Operator Initials on Old Controller



Press 'Enter' on the controller keypad to view the Main Menu.



Select which operator initial to edit or add. (1, 2, or 3)



Press 'F3' for Advanced Menu and type the code '1123'.

(Do not press **'enter'** after putting in the code as this will return to the Main Menu)




Use 'F1' and 'F2' to set the first character. Press 'F4' to select the next character placeholder and adjust accordingly with 'F1' and 'F2'.

Press 'Enter' to save.



Press 'F3' to select Operator Initials



Press 'Enter' twice more to return to Auto Mode.

UC Davis General Lab: 530-752-1123

IMPROVE operator training videos: https://aqrc.ucdavis.edu/resources-for-operators









Change Date/Time on New Controller


(If the controller is connected to the internet please only edit the time zone)




Press the 'Menu' on the home screen.



Press 'Time Zone'




Press 'Settings'



Use up/down arrows to select the time zone offset based on step 3




Look up your time zone on the reference map and note the corresponding GMT offset in **Bold**




Only if your site is **not** connected to the internet do you select the "Date and Time' option in step 4 to manually edit the time.

Press the ricon to edit the time


Test Network Connection and Send Data to Server




Press the 'Menu' on the home screen.




Press 'Ping'



Press 'Equipment Tests'



Read the output of the test. If the 2nd to last line reads '5 packets transmitted, 5 received, 0% packet loss' then the controller is successfully connected to the internet



Press 'Network Test'




Press the button to go back to 'Network Tools' then select the 'R-Sync' option. This will send the controller data back to the server.






Manage Operator Initials on New Controller



Press the 'Menu' on the home screen.



Select the initials you wish to remove, then press 'Remove'

If you wish to add initials press 'Add'




Press 'Settings'



When adding initials use the up/down arrows to edit a letter, and left/right arrows to move the cursor.

Please use 3 letter initials for clarity.



Press 'Operator Initials'





JANUARY 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|----------------------------------|--|---|----------------------------------|----------------------------------|---|---|
| | 31 | New Year's Day 1 | 2 | 3 | 4 | 5 |
| | | 3-2-2 Week 3 2-3-2 Week 1 | | | | Z. |
| | | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 6 | 7 | 3-2-2 Week 1 2-3-2 Week 2 | 9 | 10 | 11 | 12 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 13 | 14 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old | 16 | 17 | 18 | 19 |
| | | cartridge to new. | | | | |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 20 | Martin Luther 21 King, Jr. Day | 3-2-2 Week 3 2-3-2 Week 1 | 23 | 24 | 25 | 26 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 27 | 28 | 3-2-2 Week 1 2-3-2 Week 2 | 30 | 31 | DECEMBER 2018 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 | FEBRUARY 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | 16 17 18 19 20 21 22 23 24 25 26 27 28 29 | 17 18 19 20 21 22 23 24 25 26 27 28 |



FEBRUARY 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|----------------------------------|----------------------------------|--|----------------------------------|--------------------------------|--|---|
| 27 | 28 | 29 | 30 | 31 | 1 | 2 |
| | | | | | | IMPROVE Particle Sampling Day |
| 3 | 4 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 6 | 7 | 8 | 9 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 10 | 11 | 3-2-2 Week 3 2-3-2 Week 1 | 13 | 14 IMPROVE Particle | 15 | 16 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | Sampling Day | | |
| 17 | President's Day 18 | 3-2-2 Week 1 2-3-2 Week 2 | 20 | 21 | 22 | 23 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 24 | 25 | 3-2-2 Week 2 26 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 27 | 28 | JANUARY 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 | MARCH 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | 27 28 29 30 31 | 17 18 19 20 21 22 23 24 31 25 26 27 28 29 30 |



MARCH 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|------------------------------------|--------------------------------|--|----------------------------------|--------------------------------|--|--|
| 24 | 25 | 26 | 27 | 28 | 1 IMPROVE Particle Sampling Day | 2 |
| 3 | IMPROVE Particle | 3-2-2 Week 3 2-3-2 Week 1 Change IMPROVE | Alternate Sample | 7 IMPROVE Particle | 8 | 9 |
| 10 | Sampling Day 11 | Particle cartridges 3-2-2 Week 1 2-3-2 Week 2 | Change Day 13 | Sampling Day 14 | 15 | 16 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 17 | 18 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 20 | 21 | 22 IMPROVE Particle | 23 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | Sampling Day | |
| 24 | 25 IMPROVE Particle | 3-2-2 Week 3 2-3-2 Week 1 Change IMPROVE | 27 Alternate Sample | 28 IMPROVE Particle | 29 | 30 |
| | Sampling Day | Particle cartridges | Change Day | Sampling Day | | |
| 31 IMPROVE Particle Sampling Day | 1 | 2 | 3 | 4 | FEBRUARY 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 | **Notation** ** |



APRIL 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|----------------------------------|----------------------------------|---|----------------------------------|----------------------------------|---|--|
| 31 | 1 | 3-2-2 Week 1 2-3-2 Week 2 | 3 | 4 | 5 | 6 |
| | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 7 | 8 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 10 | 11 | 12 | 13 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 14 | 15 | 3-2-2 Week 3 2-3-2 Week 1 | 17 | 18 | 19 | 20 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 21 | 22 | 3-2-2 Week 1 2-3-2 Week 2 | 24 | 25 | 26 | 27 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 28 | 29 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 1 | 2 | MARCH 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 | MAY 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | dia | | 17 18 19 20 21 22 23 24 31 25 26 27 28 29 30 | 19 20 21 22 23 24 25 26 27 28 29 30 31 |



MAY 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|--|--|--|--------------------------------|-----------------------------------|--|------------------------------------|
| S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 | S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 3 24 25 26 27 28 29 | 30 | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | 4 |
| 5 | 6 IMPROVE Particle Sampling Day | 3-2-2 Week 3 2-3-2 Week 1 Change IMPROVE Particle cartridges | Alternate Sample Change Day | 9 IMPROVE Particle Sampling Day | 10 | 11 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | 3-2-2 Week 1 2-3-2 Week 2 Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | 16 | 17 | 18 IMPROVE Particle Sampling Day |
| Alternate Sample Change Day | Alternate Sample Change Day | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | 24 IMPROVE Particle Sampling Day | 25 |
| 26 | Memorial Day 27 IMPROVE Particle Sampling Day | 3-2-2 Week 3 2-3-2 Week 1 Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | 31 31 | 1 |
| | | | 440 | | | |



JUNE 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|--|--|--|--|--|---|---|
| 26 | 27 | 28 | 29 | 30 | 31 | 1 |
| 2 IMPROVE Particle Sampling Day | Alternate Sample Change Day | 3-2-2 Week 1 2-3-2 Week 2 Change IMPROVE Particle cartridges | 5 IMPROVE Particle Sampling Day | 6 | 7 | 8 IMPROVE Particle Sampling Day |
| 9 Alternate Sample Change Day | Alternate Sample Change Day | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | 14 IMPROVE Particle Sampling Day | 15 |
| 16 | 17 IMPROVE Particle Sampling Day | 3-2-2 Week 3 2-3-2 Week 1 Change IMPROVE Particle cartridges | Alternate Sample Change Day | 20 IMPROVE Particle Sampling Day | 21 | 22 |
| 23 IMPROVE Particle Sampling Day | Alternate Sample Change Day | 3-2-2 Week 1 2-3-2 Week 2 Change IMPROVE Particle cartridges | 26 IMPROVE Particle Sampling Day | 27 | 28 | 29 IMPROVE Particle Sampling Day |
| 30 Alternate Sample Change Day | 1 | 2 | 3 | 4 | MAY 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 | S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 |



JULY 2019

| | SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|----|----------------------------------|----------------------------------|---|----------------------------------|----------------------------------|--|---|
| a. | 30 | 1 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 3 | Independence Day 4 | 5 | 6 |
| | | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| | 7 | 8 | 3-2-2 Week 3 2-3-2 Week 1 | 10 | 11 | 12 | 13 |
| | | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| | 14 | 15 | 3-2-2 Week 1 2-3-2 Week 2 | 17 | 18 | 19 | 20 |
| | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| | 21 | 22 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 24 | 25 | 26 | 27 |
| | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| | 28 | 29 | 3-2-2 Week 3 2-3-2 Week 1 | 31 | 1 | JUNE 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 | AUGUST 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 |
| | | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | | 23 30 24 25 26 27 28 29 | 25 26 27 28 29 30 31 |



AUGUST 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|---|---|--|--|---|--|----------------------------------|
| S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 | SEPTEMBER 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 | 30 | 31 | 1 IMPROVE Particle Sampling Day | 2 | 3 |
| 4 IMPROVE Particle Sampling Day | Alternate Sample Change Day | 3-2-2 Week 1 2-3-2 Week 2 Change IMPROVE Particle cartridges | 7 IMPROVE Particle Sampling Day | 8 | 9 | IMPROVE Particle Sampling Day |
| Alternate Sample Change Day | Alternate Sample Change Day | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. IMPROVE Particle Sampling Day | 14 Alternate Sample Change Day | Alternate Sample Change Day | 16 IMPROVE Particle Sampling Day | 17 |
| 18 | 19 IMPROVE Particle Sampling Day | 3-2-2 Week 3 2-3-2 Week 1 Change IMPROVE Particle cartridges | Alternate Sample Change Day | 22 IMPROVE Particle Sampling Day | 23 | 24 |
| 25 | 26 | 3-2-2 Week 1 2-3-2 Week 2 | 28 | 29 | 30 | 31 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |



SEPTEMBER 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|----------------------------------|----------------------------------|--|----------------------------------|----------------------------------|---|---|
| 1 | Labor Day 2 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 4 | 5 | 6 | 7 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 8 | 9 | 3-2-2 Week 3 2-3-2 Week 1 | 11 | 12 | 13 | 14 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 15 | 16 | 3-2-2 Week 1 2-3-2 Week 2 | 18 | 19 | 20 | 21 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 22 | 23 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 25 | 26 | 27 | 28 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 29 | IMPROVE Particle Sampling Day | 1 | 2 | 3 | S M T W T S S 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 | S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 |



OCTOBER 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|----------------------------------|----------------------------------|--|----------------------------------|----------------------------------|--|--|
| 29 | 30 | 3-2-2 Week 3 2-3-2 Week 1 | 2 | 3 | 4 | 5 |
| | | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 6 | 7 | 3-2-2 Week 1 2-3-2 Week 2 | 9 | 10 | 11 | 12 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 13 | Columbus Day 14 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 16 | 17 | 18 | 19 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 20 | 21 | 3-2-2 Week 3 2-3-2 Week 1 | 23 | 24 | 25 | 26 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 27 IMPROVE Particle | 28 Alternate Sample | 3-2-2 Week 1 2-3-2 Week 2 29 Change IMPROVE | 30 IMPROVE Particle | 31 | SEPTEMBER 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 | NOVEMBER 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 |
| Sampling Day | Change Day | Particle cartridges | Sampling Day | | 29 30 | 24 25 26 27 28 29 30 |




NOVEMBER 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|---|---|--|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 | DECEMBER 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 | 29 | 30 | 31 | 1 | IMPROVE Particle Sampling Day |
| 3 | 4 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 6 | 7 | 8 | 9 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 10 | Veteran's Day 11 | 3-2-2 Week 3 2-3-2 Week 1 | 13 | 14 | 15 | 16 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 17 | 18 | 3-2-2 Week 1 2-3-2 Week 2 | 20 | 21 | 22 | 23 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 24 | 25 | 3-2-2 Week 2 26 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 27 | Thanksgiving Day 28 | 29 | 30 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |



DECEMBER 2019

| SUNDAY | MONDAY | TUESDAY | WEDNESDAY | THURSDAY | FRIDAY | SATURDAY |
|----------------------------------|----------------------------------|---|----------------------------------|----------------------------------|----------------------------------|---|
| 1 | 2 | 3-2-2 Week 3 2-3-2 Week 1 | 4 | 5 | 6 | 7 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 8 | 9 | 3-2-2 Week 1 2-3-2 Week 2 | 11 | 12 | 13 | 14 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | IMPROVE Particle Sampling Day | | | IMPROVE Particle Sampling Day |
| 15 | 16 | 3-2-2 Week 2 2-3-2 Week 3 Special cartridge change: move cassette 3 from old cartridge to new. | 18 | 19 | 20 | 21 |
| Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | Alternate Sample Change Day | Alternate Sample Change Day | IMPROVE Particle Sampling Day | |
| 22 | 23 | 3-2-2 Week 3 2-3-2 Week 1 | Christmas Day 25 | 26 | 27 | 28 |
| | IMPROVE Particle Sampling Day | Change IMPROVE Particle cartridges | Alternate Sample Change Day | IMPROVE Particle Sampling Day | | |
| 29 | 30 | 3-2-2 Week 1 2-3-2 Week 2 | 1 | 2 | 3 | NOVEMBER 2019 S M T W T F S 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 |
| IMPROVE Particle Sampling Day | Alternate Sample Change Day | Change IMPROVE Particle cartridges | 4.00 | | | 17 18 19 20 21 22 23 24 25 26 27 28 29 30 |



Photographs taken by IMPROVE Field Engineer, Josh Grant. Cover Photo: VALHALLA (Sequoia NP) Josh Grant

